

RL8110

LEG PRESS OWNER'S MANUAL

Table Of Contents

CAUTION!

Read all precautions and instructions in this manual before using this equipment.

Important Safety Instructions	3
Instructions	5
Exploded View and Parts List	6
Measurement Guide	12
Assembly Instructions	13
Assembly	14
Adjust Instructions	20
Maintenance Schedule	21
General Maintenance Information	22
Weight Training Tips	23

Important Safety Instructions

Before beginning any fitness program, you should obtain a complete physical examination from your physician. When using exercise equipment, basic precautions should always be taken, including the following:

- 1. Read all instructions before using the equipment.

 These instructions are written to ensure your safety and to protect the unit.
- 2. Use the equipment only for its intended purpose as described in this guide. Do not use accessory attachments that are not recommended by the manufacturer: such attachments might cause injuries.
- 3. The product should only be used on a level surface and is with 0.5 meters space around the product.

 Do not use the equipment outdoors.
- 4. Do not allow children on or near the equipment. And children are not allowed to use this equipment.

 Teenagers should use this equipment with adult supervision.
- 5. Do not overexert yourself or work to exhaustion. Do not attempt to lift more weight than you can control safely. If you feel any pain or abnormal symptoms, stop your workout immediately and consult your physician.
- 6. This equipment is not used as medical apparatus and instruments.
- 7. Never operate the unit when it has been dropped or damaged. Never drop or insert anything into any opening in the equipment. Always check the unit and its cables before each use. Make sure that all fasteners and cables are secure and in good working condition. Frayed or worn cables can be dangerous and may cause injury. Periodically check these cables for any indication of wear. Keep hands, limbs, loose clothing and long hair well out of the way of moving parts.
- 8. Be careful when getting on or off the equipment.
- 9. Wear proper exercise clothing and shoes for your workout, no loose clothing.


Important Safety Instructions

Personal Safety During Assembly

Read each step in the assembly instructions and follow the steps in sequence. Do not skip ahead. If you skip ahead, you may learn later that you have to disassemble components and that you may have damaged the equipment.

Assemble and operate the equipment on a solid, level surface. Locate the unit a few feet from walls or furniture to provide easy access. The equipment is designed for your enjoyment. By following these precautions and using common sense, you will have many safe and pleasurable hours of healthful exercise with the equipment.

Training Area and Free Area



Specifications

Class: S

Maximum User Weight: 150kg/ 330lbs Product Total Surface: 734*1737mm


Product Total Mass:

Instructions

Before beginning assembly please take the time to read instructions thoroughly. Please use the various lists in this manual to make sure that all parts have been included in your shipment. When ordering, use part number and description from the lists. Use only our replacement part when servicing. Failure to do so will void your warranty and could result in personal injury.

The equipment is designed to provide the smoothest, most effective exercise motion possible. After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call your authorized dealer. Be sure to have your serial number and this manual when calling. When all parts have been accounted for, continue on.


Tools Required




Overall

Item No.	Grade No.	Part No.	Description	QTY
1	1	RL811001ASSY	Main Frame ASSY	1
2	2	RL810102ASSY	Back Pad Frame ASSY	1
3	3	RL811003ASSY	Front Swing Frame ASSY	1
4	4	RL811004ASSY	Rear Swing Frame ASSY	1
5	5	RL811005ASSY	Foot Rack ASSY	1
6	6	IF93242100	Shaftφ25*110	4
7	7	RL81015100	Seat Pad	1
8	8	RL81013100	Decorative Sleeve	1
9	9	RL81014000	Cup Holder	1
10	10	ST56-540FASSY	Hydro-Cylinder ASSY	1
11	11	RL81073100	Decorative Boards	1
12	12	IE950716500	φ60*11.6 Aluminium Cap	8
13	13	GB9310N19	Spring Washer φ10	5
14	14	GB9510DN2	Flat Washer φ11*φ20*2	7
15	15	NM10DN2	Nylon Lock Nut M10	2
16	16	GB845ST4.2*16N19	Screw ST4.2*16	4
17	17	GB70BTM10*105DN18	Socket Head Cap Screw M10*105	1
18	18	CNLM10*30*30DN20	Flat Head Cap Screw M10*30	8
19	19	GB70BTM10*30DN18	Socket Head Cap Screw M10*30	6
20	20	PNLM10*40N19	Button Head Cap Screw M10*40	2
21	21	RL81013800	Fixed Button	4
22	22	NBS6DS	Hex Key S=6	1
23	23	LW200BS	Wrench	1

Overall




Main Frame ASSY



ItemNo.	Grade No.	Part No.	Description	QTY
1	1.1	RL81100100	Main Frame	1
2	1.2	RS17000400	Urethane Bumper	1
3	1.3	B4002200	Rear End Cap	2
4	1.4	B4001600	Endcap with Wheel	2
5	1.5	026-01PL0206-12	Grip STφ31*φ24*130	2
6	1.6	V39500	φ25.4 Aluminium Grip Ring	2
7	1.7	CWRVL0051800	φ25 Aluminium Grip Cap	2
8	1.8	GB819M5*15N19	Flat Head Cap Screw M5*15	4
9	1.9	GB70BTM10*20DN18	Socket Head Cap Screw M10*20	2
10	1.10	YZGB7710-32*3.2N19	Socket Set Screw 10-32UNF*3.2	8


Back Pad Frame ASSY



ItemNo.	Grade No.	Part No.	Description	QTY
1	2.1	RL81010200	Back Pad Frame	1
2	2.2	RL81013200	Back Pad Cover	1
3	2.3	RL81013300	Head Pad Cover	1
4	2.4	RL81015200	Back Pad	1
5	2.5	RL81015300	Head Pad	1
6	2.6	GB70BTM10*30DN18	Socket Head Cap Screw M10*30	6

Front Swing Frame ASSY

Rear Swing Frame ASSY





ItemNo.	Grade No.	Part No.	Description	QTY
1	3.1	RL81100300	Front Swing Frame	1
2	3.2	FE97085100	Bushing Ф38*Ф25*7.5	4

ItemNo.	Grade No.	Part No.	Description	QTY
1	4.1	RL81100400	Rear Swing Frame	1
2	4.2	GB2766205-2ZC3	Deep Groove Ball Bearing Φ25*Φ52*15	4

Foot Rack ASSY

Hydro-Cylinder ASSY






ItemNo.	Grade No.	Part No.	Description	QTY
1	5.1	RL81100500	Foot Rack	1
2	5.2	RL81103100	Footplate	1
3	5.3	RS17000400	Urethane Bumper	1
4	5.4	GB70BTM10*20DN18	Socket Head Cap Screw M10*20	2

ItemNo.	Grade No.	Part No.	Description	QTY
1	10.1	ST56-540F	Hydro-Cylinder	1
2	10.2	RL81103500	Hydro-Cylinder Cover A	1
3	10.3	RL81103600	Hydro-Cylinder Cover B	1
4	10.4	GB845ST4.2*25DS	Cross Recessed screw ST4.2*25	6

Measurement Guide



Diameter of bolt (mm/inch)	M6(1/4")	M8(5/16")	M10(3/8")	M12(1/2")	M16(5/8")
Tightening torque (N.m)	9~12	22~30	45~59	78~104	193~257
Operational methods for adult men	The strength of the wrist	The strength of the wrist and forearm	The strength of the entire arm	The strength of the arm and upper body	with all strength

Assembly Instructions

Assembly of the equipment takes professional installers about 2 hours. If this is the first time you have assembled this type of equipment, plan to spend more time. It is strongly recommended to assemble the equipment by professional installers. You may find it quicker, safer, easier to assemble this equipment with the help of a friend, as some of components may be large, heavy or awkward to handle alone. It is important that you assemble your product in a clean, clear, uncluttered area. This will enable you to move around the product while you are fitting components and reduce the possibility of injury during assembly.

№ NOTE

As with any assembled part, proper alignment and adjustment is critical. While tightening the fasteners, be sure to leave room for adjustments. Do not fully tighten the fasteners until instructed to do so. Be careful to assemble the components in the sequence presented in this guide.


STEP 1

- 1. Attach one Decorative Sleeve (#8) to the Main Frame ASSY (#1).
- 2. Attach the Cup Holder (#9) to the Back Pad Frame ASSY (#2) using: four ST4.2*16 Screw (#16)

Note: Wrench Tighten Bolts.

STEP 2

Attach the Back Pad Frame ASSY (#2) to the Main Frame ASSY (#1) using: four M10*30 SHCS (#19)



STEP 3


Attach the Rear Swing Frame ASSY (#4) and one Shaft Φ 25*110 (#6) to Main Frame ASSY (#1) using:

two Φ60*Φ11.6 Aluminium Cap (#12)

two M10*30 FHCS (#18)

Note: 1. Make sure up this end, which with a sticker.

2. Wrench Tighten Bolts.




STEP 4

Attach the Front Swing Frame ASSY (#3) and one Shaft Φ 25*110 (#6) to Main Frame ASSY (#1) using:

two Φ60*Φ11.6 Aluminium Cap (#12)

two M10*30 FHCS (#18)

Note: Wrench Tighten Bolts.




STEP 5

Attach the Foot Rack ASSY (#5) and two Shaft Φ 25*110 (#6) to the Front Swing Frame ASSY (#3) and the Rear Swing Frame ASSY (#4) using:

four Φ60*Φ11.6 Aluminium Cap (#12)

four M10*30 FHCS (#18)

Note: Wrench Tighten Bolts.



STEP 6

Attach the Hydro-Cylinder ASSY (#10) to the Main Frame ASSY (#1) and the Rear Swing Frame ASSY (#4) using:


two M10*40 BHCS (#20)

four Φ11*Φ20*2 Flat Washer (#14)

two M10 Nylon Lock Nut (#15)

Note:

- 1. Wrench Tighten Bolts and Nylon Lock Nuts.
- 2. The Adjustment Knob of the Hydro-Cylinder points forwards.
- 3. Before using the machine, please make sure the Adjustment Knob upwards and tighten the HEX Nut.




STEP 7

1. Attach the Seat Pad (#7) to the Main Frame ASSY (#1) using: two M10*30 SHCS (#19) two Φ 11* Φ 20*2 Flat Washer (#14)

2. Attach the ecorative Boards (#11) to the Main Frame ASSY (#1) using: four Fixed Button (#21)


Note: Wrench Tighten Bolts.



Adjust Instructions

Instructions

- 1. Select an appropriate Lever by Adjusting the Adjustment Knob.
- 2. Make sure the Adjustment Knob upwards.
- 3. The moving wheels are of benefit when you adjust the machine's position.



Maintenance Schedule

ROUTINE	COMMERCIAL MAINTENANCE	HOME MAINTENANCE	LATEST DATE ENTRY					
Inspect; Links, Pull Pins, Snap Locks, Swivels, Weight Stack Pins	DAILY	WEEKLY						
Clean; Upholstery	DAILY	WEEKLY						
Inspect; Cables or Belts and their tension	DAILY	WEEKLY						
Inspect; Accessory Bars, and Handles	WEEKLY	3 MONTHS						
Inspect; All Decals	WEEKLY	3 MONTHS						
Inspect; All Nuts and Bolts, Tighten if needed	WEEKLY	3 MONTHS						
Inspect; Anti-Skid Surface	WEEKLY	3 MONTHS						
Clean & Lubricate; Guide Rods with a Teflon (PTFE) based lubricant (Superlube)	MONTHLY	3 MONTHS						
Lubricate; Seat Sleeves, Turcite Bushings, Linear Bearing	MONTHLY	3 MONTHS						
Clean and Wax; All Glossy Finishes	6 MONTHS	YEARLY						
Repack with Grease; Linear Bearings	6 MONTHS	YEARLY						
Replace; Cables, Belts and Connecting Parts	YEARLY	3 YEARS						

Your equipment comes with a commercial maintenance decal. For personal, in home use, please follow the home maintenance schedule listed above.

General Maintenance Information

Links, Pull-Pins, Snap Hooks, Swivels, Weight Stack Pins:

- * Check all pieces for signs of visible wear or damage.
- * Check springs in snap hooks and pull-pins for proper tension and alignment.
- * If the spring sticks or has lost its rigidity, replace it immediately.

Upholstery:

- * To ensure prolonged upholstery life and proper hygiene, all upholstered pads should be wiped down with a damp cloth after every workout.
- * Periodically take the time to use a mild soap or an approved vinyl upholstery cleaner to deter the onset of cracking or drying. Avoid using any abrasive cleaners or cleaners not intended for use on vinyl.
- * Replace ripped or warn upholstery immediately.
- * Keep sharp or pointed objects clear of all upholstery.

Decals:

* Inspect and familiarize yourself with any safety warnings or other user information posted on each decal.

Nuts and Bolts:

- * Inspect all nuts and bolts for any loosening and tighten if needed.
- * Go through a re-tightening sequence periodically to ensure that all hardware is tensioned proper.

Anti-Skid Surfaces:

*These surfaces are designed to supply secure footing and need to be replaced if they appear worn or become slippery.

Belts and Cables:

- * We uses only high quality belt, and mil-spec cables.
- * Visually inspect the belts and cables for fraying, cracking, peeling or discoloration.
- * While the machine is not in use, carefully run your fingers along the belt or cable to feel for thinning or bulging areas.
- * Replace belts and cables immediately at the first signs of damage or wear. Do not use equipment until belts or cables have been replaced.

Belt and Cable Tension:

- * Referring to the Owners Manual, when belts or cables are used check all bolts attachments to be sure they are properly attached.
- * Check slack in cables and re-adjust cable tension if needed.

Seat Sleeves, Guide Rods:

- * Wipe down adjusting tubes with a dust free rag before applying lubricant.
- * Lubricate seat sleeves and Guide Rods with a Silicon or Teflon based lubricant spray.

Linear Bearings:

* Referring to the Owners Manual carefully disassemble the bearing from its housing and place a finger full of light grease (lithium, super lube, etc.) into the inside of the bearing. Using your finger, press the grease into the ball-bearings and their tracks. repeat until the ball-bearing tracks are full of grease. Insert the shaft back into the bearing and wipe off excess grease.

PLEASE KEEP THIS FOR YOUR RECORDS

Weight Training Tips

Use this manual to guide you through the basic exercises you can perform on your equipment. To gain maximum results and avoid possible injury, consult a fitness professional to develop your complete exercise program.

Always consult your physician before starting any exercise program.

To be successful in your exercise program, it is important to develop an understanding of the basic principles of strength training. Now that you have your equipment, it is only natural that you want to get started immediately. First, determine a set of realistic goals and objectives for yourself. By deciding on an exercise plan that is right for you prior to starting, you will contribute significantly to your success.

Warm up properly before engaging in weight resistance training. Stretching, yoga, jogging, calisthenics or other cardiovascular exercise can help prepare your body for the heavier workload of lifting weights.

Learn how to perform the exercise correctly before using heavy weight. Correct form is important to avoid injury and to ensure that you work the proper muscle groups.

Know your limitations. If you are new to weight training or are embarking on an exercise regimen after a long layoff, start slowly and build foundational strength over a longer period of time.

Pay attention to your breathing. Exhale when you exert is a general rule of thumb. Never hold your breath.







